

Mobile Phones	
Manufacturer	Phone Model
Alcatel	Alcatel One Touch 500
Alcatel	Alcatel One Touch 535
Alcatel	Alcatel One Touch 565
Alcatel	Alcatel One Touch 715
Alcatel	Alcatel One Touch 735
Alcatel	Alcatel One Touch 756
Alcatel	Alcatel OT-C717
Alcatel	Alcatel OTS853
Amoi	Amoi 9507
BENQ-SIEMENS	BenQ AL26 Kitty
BENQ-SIEMENS	Benq Siemens E71
BENQ-SIEMENS	BenQ-Siemens EF91
Ericsson	Ericsson R310S
Ericsson	Ericsson R320
Ericsson	Ericsson R520
Ericsson	Ericsson T39
Ericsson	Ericsson T65
Ericsson	Ericsson T68
Ericsson	Ericsson T68i
Global Wireless Inc	Global Wireless Incorporated 881U
HTC	HTC SmartPhone
LG	LG Electronics KP230
LG	LG Electronics KP233
LG	LG Electronics KP260
LG	LG Electronics KP293 i-mode
LG	LG Elec. Inc GW520
LG	LG Elec. Inc KE600
LG	LG Elec. Inc KF510
LG	LG Elec. Inc KF600
LG	LG Elec. Inc KF900
LG	LG Elec. Inc KM380
LG	LG Elec. Inc KP500
LG	LG Elec. Inc KS360
LG	LG C3300
LG	LG EDS
LG	LG EDS-003
LG	LG Electronics KU580
LG	LG Electronics U8 Series
LG	LG G4050
LG	LG G5400
LG	LG KE500
LG	LG KE590I
LG	LG KE850 Prada
LG	LG KE970 Shine
LG	LG KG220
LG	LG KG291 i-mode
LG	LG KG800
LG	LG KG810
LG	LG KU385
LG	LG L343i
LG	LG L600V

LG	LG P7200
LG	LG U300
LG	LG U8110
LG	LG U8210
LG	LG U8500
LG	LG U880
LG	LG U900
LG	LG Electronics 226
LG	LG Electronics CU515
LG	LG Electronics GT505
LG	LG Electronics Inc. 116
LG	LG Electronics Inc. C3320
LG	LG Electronics Inc. C3380
LG	LG Electronics Inc. F2100
LG	LG Electronics Inc. F3000
LG	LG Electronics Inc. G7050
LG	LG Electronics Inc. KG208
LG	LG Electronics Inc. KG320
LG	LG Electronics Inc. KG920
LG	LG Electronics Inc. LG-G7100
LG	LG Electronics Inc. S5100
LG	LG Electronics Inc. S5200
LG	LG Electronics KF750
LG	LG Electronics KS500
LG	LG Electronics KU450
LG	LG Electronics U890
LG	GU280
LG	LG Electronics Inc BL40
LG	LG Electronics Inc GB250
LG	LG Electronics Inc GC900
LG	LG Electronics Inc GD900
LG	LG Electronics Inc KC910
LG	LG Electronics Inc KC910-H3G
LG	LG Electronics Inc KM900
LG	LG Electronics Inc KP270
Mitsubishi	Mitsubishi M342
Motorola	I250-000
Motorola	K1
Motorola	L7
Motorola	PEBL U6
Motorola	V195
Motorola	V525M
Motorola	V600
Motorola	V620
Motorola	MODEL=Z3
Motorola	C650
Motorola	E398
Motorola	L6
Motorola	V180
Motorola	V220
Motorola	V235
Motorola	A835
Motorola	E770v

Motorola	RAZRV3xv
Motorola	V1050
Motorola	K3
Motorola	RAZRV9
Motorola	RAZRV6
Motorola	RIZR
Motorola	Motorola C350
Motorola	Motorola C350
Motorola	Motorola C390
Motorola	Motorola CE 280
Motorola	Motorola CE A1000
Motorola	Motorola CE A835
Motorola	Motorola CE A925
Motorola	Motorola CE C330
Motorola	Motorola CE C330 (GSM)
Motorola	Motorola CE C350
Motorola	Motorola CE C385
Motorola	Motorola CE C385
Motorola	Motorola CE C450
Motorola	Motorola CE C550
Motorola	Motorola CE C650
Motorola	Motorola CE C975
Motorola	Motorola CE C980M
Motorola	Motorola CE E1000
Motorola	Motorola CE E1000M
Motorola	Motorola CE E1000M
Motorola	Motorola CE E1070
Motorola	Motorola CE E398
Motorola	Motorola CE E398B
Motorola	Motorola CE E550
Motorola	Motorola CE E770v
Motorola	Motorola CE K1v
Motorola	Motorola CE KRZR K1
Motorola	Motorola CE PEBL U6
Motorola	Motorola CE RAZR V3c
Motorola	Motorola CE RAZR V3xv
Motorola	Motorola CE RAZR V3xx
Motorola	Motorola CE RAZR V3xxv
Motorola	Motorola CE ROKR
Motorola	Motorola CE SLVR
Motorola	Motorola CE T720i
Motorola	Motorola CE V1100
Motorola	Motorola CE V150
Motorola	Motorola CE V180
Motorola	Motorola CE V220
Motorola	Motorola CE V235
Motorola	Motorola CE V300
Motorola	Motorola CE V300
Motorola	Motorola CE V360
Motorola	Motorola CE V3c
Motorola	Motorola CE V3r
Motorola	Motorola CE V3v
Motorola	Motorola CE V500

Motorola	Motorola CE V500
Motorola	Motorola CE V545
Motorola	Motorola CE V547
Motorola	Motorola CE V550
Motorola	Motorola CE V550
Motorola	Motorola CE V551
Motorola	Motorola CE V60
Motorola	Motorola CE V620
Motorola	Motorola CE V635
Motorola	Motorola CE V66
Motorola	Motorola CE V66i
Motorola	Motorola CE V80
Motorola	Motorola CE V835
Motorola	Motorola CE V975
Motorola	Motorola CE V980
Motorola	Motorola CE V980M
Motorola	Motorola CE V980M
Motorola	Motorola CE Z3
Motorola	Motorola E1 iTunes
Motorola	Motorola i250
Motorola	Motorola KRZR K1 T
Motorola	Motorola KRZR K3
Motorola	Motorola L Series
Motorola	Motorola L2
Motorola	Motorola L6
Motorola	Motorola L6-imode
Motorola	Motorola L6i
Motorola	Motorola L7-imode
Motorola	Motorola MAXX V6
Motorola	Motorola Ming/A1200e
Motorola	Motorola Q q9
Motorola	Motorola RAZR Maxx V3
Motorola	Motorola RAZR maxx V6
Motorola	Motorola RAZR V3
Motorola	Motorola RAZR V3i
Motorola	Motorola RAZR V3xM
Motorola	Motorola RAZR V3xx
Motorola	Motorola RAZR V3xxi
Motorola	Motorola RAZR V6vb
Motorola	Motorola RAZR V6vc
Motorola	Motorola RAZR2 V8
Motorola	Motorola RAZR2 V9
Motorola	Motorola RAZRV3x
Motorola	Motorola RIZR Z8
Motorola	Motorola Timeport
Motorola	Motorola Timeport 280
Motorola	Motorola V1050
Motorola	Motorola V1075
Motorola	Motorola V1075
Motorola	Motorola V1075
Motorola	Motorola V3
Motorola	Motorola V360
Motorola	Motorola V3iv

Motorola	Motorola V3re
Motorola	Motorola V400
Motorola	Motorola V525M
Motorola	Motorola V600
Motorola	Motorola V70
Motorola	V3ire
Motorola	V3iv
Motorola	V3r
Motorola	V3re
Motorola	V3v
Motorola	A1000
Motorola	V980
Motorola	E8
Motorola	E8_CMCC
Motorola	U9
Motorola	Z6
Motorola	E1 iTunes
Motorola	EM330
Motorola	G24
NEC	NEC 338
NEC	NEC Corporation e540
Nokia	Nokia 12i
Nokia	Nokia 2760
Nokia	Nokia 3109 classic
Nokia	Nokia 3110c
Nokia	Nokia 3200
Nokia	Nokia 3220
Nokia	Nokia 3230
Nokia	Nokia 3250
Nokia	Nokia 3500 classic
Nokia	Nokia 3650
Nokia	Nokia 3650
Nokia	Nokia 3660
Nokia	Nokia 5100
Nokia	Nokia 5140
Nokia	Nokia 5140i
Nokia	Nokia 5200
Nokia	Nokia 5210
Nokia	Nokia 5300
Nokia	Nokia 5310 XpressMusic
Nokia	Nokia 5610 XpressMusic
Nokia	Nokia 5700
Nokia	Nokia 6020
Nokia	Nokia 6021
Nokia	Nokia 6070
Nokia	Nokia 6080
Nokia	Nokia 6085
Nokia	Nokia 6100
Nokia	Nokia 6101
Nokia	Nokia 6102
Nokia	Nokia 6103
Nokia	Nokia 6110
Nokia	Nokia 6111

Nokia	Nokia 6120
Nokia	Nokia 6125
Nokia	Nokia 6131
Nokia	Nokia 6150
Nokia	Nokia 6151
Nokia	Nokia 6170
Nokia	Nokia 6200
Nokia	Nokia 6210
Nokia	Nokia 6220
Nokia	Nokia 6230
Nokia	Nokia 6230i
Nokia	Nokia 6233
Nokia	Nokia 6234
Nokia	Nokia 6267
Nokia	Nokia 6270
Nokia	Nokia 6280
Nokia	Nokia 6288
Nokia	Nokia 6290
Nokia	Nokia 6300
Nokia	Nokia 6310
Nokia	Nokia 6310i
Nokia	Nokia 6340i
Nokia	Nokia 6500c
Nokia	Nokia 6500s
Nokia	Nokia 6510
Nokia	Nokia 6555
Nokia	Nokia 6600
Nokia	Nokia 6610
Nokia	Nokia 6610i
Nokia	Nokia 6630
Nokia	Nokia 6650
Nokia	Nokia 6670
Nokia	Nokia 6680
Nokia	Nokia 6681
Nokia	Nokia 6800
Nokia	Nokia 6810
Nokia	Nokia 6820
Nokia	Nokia 6822
Nokia	Nokia 7110
Nokia	Nokia 7200
Nokia	Nokia 7210
Nokia	Nokia 7210
Nokia	Nokia 7250
Nokia	Nokia 7250i
Nokia	Nokia 7260
Nokia	Nokia 7270
Nokia	Nokia 7280
Nokia	Nokia 7360
Nokia	Nokia 7370
Nokia	Nokia 7373
Nokia	Nokia 7390
Nokia	Nokia 7500
Nokia	Nokia 7600

Nokia	Nokia 7610
Nokia	Nokia 7650
Nokia	Nokia 7710
Nokia	Nokia 7900 Prism
Nokia	Nokia 8210
Nokia	Nokia 8250
Nokia	Nokia 8310
Nokia	Nokia 8800
Nokia	Nokia 8800 Sirocco
Nokia	Nokia 8850
Nokia	Nokia 8890
Nokia	Nokia 8910
Nokia	Nokia 8910i
Nokia	Nokia 9210
Nokia	Nokia 9300
Nokia	Nokia 9300i
Nokia	Nokia 9500
Nokia	Nokia Communicator
Nokia	Nokia E50
Nokia	Nokia E51
Nokia	Nokia E60
Nokia	Nokia E61 Smartphone
Nokia	Nokia E61i
Nokia	Nokia E65
Nokia	Nokia E70
Nokia	Nokia E90
Nokia	Nokia N-Gage
Nokia	Nokia N.GAGE QD
Nokia	Nokia N70
Nokia	Nokia N71-1
Nokia	Nokia N72/73
Nokia	Nokia N73
Nokia	Nokia N76
Nokia	Nokia N80
Nokia	Nokia N81
Nokia	Nokia N82
Nokia	Nokia N86 8MP
Nokia	Nokia N90
Nokia	Nokia N91
Nokia	Nokia N91-2
Nokia	Nokia N92
Nokia	Nokia N93
Nokia	Nokia N93i
Nokia	Nokia N95
Nokia	Nokia N95 8GB
Nokia	Nokia N95 8GB
Nokia	Nokia 6710
Nokia	Nokia 6720
Nokia	Nokia 7100s-2
Nokia	CS-10
Nokia	CS-15
Nokia	Nokia E52
Nokia	Nokia N77

Nokia	Nokia N79
Nokia	Nokia N97
Nokia	Nokia Nokia 2323c-2
Nokia	Nokia Nokia 2330c-2
Nokia	Nokia Nokia 2600c
Nokia	Nokia Nokia 2600c-2
Nokia	Nokia Nokia 2630
Nokia	Nokia Nokia 2660
Nokia	Nokia Nokia 2680s-2
Nokia	Nokia Nokia 2700 classic
Nokia	Nokia Nokia 2730 classic
Nokia	Nokia Nokia 3120 classic
Nokia	Nokia Nokia 3610a
Nokia	Nokia Nokia 3710 fold
Nokia	Nokia Nokia 3720c
Nokia	Nokia Nokia 5000d-2
Nokia	Nokia Nokia 5070
Nokia	Nokia Nokia 5130
Nokia	Nokia Nokia 5130c-2
Nokia	Nokia Nokia 5220 XpressMusic
Nokia	Nokia Nokia 5230
Nokia	Nokia Nokia 5310
Nokia	Nokia Nokia 5320
Nokia	Nokia Nokia 5530 XpressMusic
Nokia	Nokia Nokia 5610 XpressMusic
Nokia	Nokia Nokia 5630
Nokia	Nokia Nokia 5700 XpressMusic
Nokia	Nokia Nokia 5730 XpressMusic
Nokia	Nokia Nokia 6120c
Nokia	Nokia Nokia 6136
Nokia	Nokia Nokia 6210 Navigator
Nokia	Nokia Nokia 6212 classic
Nokia	Nokia Nokia 6220c
Nokia	Nokia Nokia 6300i
Nokia	Nokia Nokia 6303 classic
Nokia	Nokia Nokia 6500s
Nokia	Nokia Nokia 6600 fold
Nokia	Nokia Nokia 6600 slide
Nokia	Nokia Nokia 6600i slide
Nokia	Nokia Nokia 6650d-1c
Nokia	Nokia Nokia 6700 classic
Nokia	Nokia Nokia 6730c-1
Nokia	Nokia Nokia 6760s-1
Nokia	Nokia Nokia 7310 Supernova
Nokia	Nokia Nokia 7610 Supernova
Nokia	Nokia Nokia 8600 Luna
Nokia	Nokia Nokia 8800e-1
Nokia	Nokia Nokia E52-1
Nokia	Nokia Nokia E55-1
Nokia	Nokia Nokia E63
Nokia	Nokia Nokia E66
Nokia	Nokia Nokia E71
Nokia	Nokia Nokia E72-1

Nokia	Nokia Nokia E75
Nokia	Nokia Nokia N78
Nokia	Nokia Nokia N79
Nokia	Nokia Nokia N85
Nokia	Nokia Nokia N86 8MP
Nokia	Nokia Nokia N96
Nokia	Nokia Nokia N96-1
Nokia	Nokia Nokia N97 mini
palmOne	Palm Treo 680
Panasonic	Panasonic GD87
Panasonic	Panasonic P341i
Panasonic	Panasonic P342i
Panasonic	Panasonic VS3
Panasonic	Panasonic X70
Panasonic	Panasonic X700
Philips	Philips 530
Philips	Philips Fisio
Philips	Philips Fisio 825
Philips	Philips Fisio 826
QUALCOMM	BRIONVEGA N7010
QUALCOMM	LG KU250
QUALCOMM	LG KU380
QUALCOMM	LG KU800 Chocolate
QUALCOMM	LG KU950
QUALCOMM	LG KU990 Viewty
QUALCOMM	LG U830
QUALCOMM	o2 Ice
QUALCOMM	Qualcomm Incorporated U970
RIM	BlackBerry
RIM	BlackBerry 8707 Series
SAGEM	Sagem MY X5-2
SAGEM	Sagem my400V GPRS
SAGEM	Sagem my401C
SAGEM	Sagem my401Z
SAGEM	Sagem my411V
SAGEM	Sagem my501C GPRS
SAGEM	Sagem my600v
SAGEM	Sagem my800X
SAGEM	Sagem my901C
SAGEM	Sagem myC5-2v
SAGEM	Sagem myV-55 GPRS
SAGEM	Sagem myV-65
SAGEM	Sagem myV-75 GPRS
SAGEM	Sagem myV-76 GPRS
SAGEM	Sagem myV-85
SAGEM	Sagem myX-6 GPRS
SAGEM	Sagem myX-7
SAGEM	Sagem myX5
SAGEM	Sagem myX5-2
SAGEM	Sagem myX6-2
Samsung	Samsung - SGH-X686
Samsung	Samsung SGH P200
Samsung	Samsung SGH U-800

Samsung	Samsung SGH Z720V
Samsung	Samsung SGH-A110
Samsung	Samsung SGH-C100
Samsung	Samsung SGH-C300
Samsung	Samsung SGH-D410
Samsung	Samsung SGH-D500
Samsung	Samsung SGH-D500E
Samsung	Samsung SGH-D520
Samsung	Samsung SGH-D600
Samsung	Samsung SGH-D600E
Samsung	Samsung SGH-D700
Samsung	Samsung SGH-D800
Samsung	Samsung SGH-D820
Samsung	Samsung SGH-D830
Samsung	Samsung SGH-D840
Samsung	Samsung SGH-D900
Samsung	Samsung SGH-D900i
Samsung	Samsung SGH-E105
Samsung	Samsung SGH-E200
Samsung	Samsung SGH-E210
Samsung	Samsung SGH-E250
Samsung	Samsung SGH-E300
Samsung	Samsung SGH-E310
Samsung	Samsung SGH-E33
Samsung	Samsung SGH-E330
Samsung	Samsung SGH-E340
Samsung	Samsung SGH-E340E
Samsung	Samsung SGH-E350
Samsung	Samsung SGH-E360
Samsung	Samsung SGH-E370
Samsung	Samsung SGH-E380
Samsung	Samsung SGH-E390
Samsung	Samsung SGH-E490
Samsung	Samsung SGH-E500
Samsung	Samsung SGH-E530
Samsung	Samsung SGH-E570
Samsung	Samsung SGH-E590
Samsung	Samsung SGH-E600
Samsung	Samsung SGH-E600C
Samsung	Samsung SGH-E620
Samsung	Samsung SGH-E63
Samsung	Samsung SGH-E700
Samsung	Samsung SGH-E710
Samsung	Samsung SGH-E710
Samsung	Samsung SGH-E720
Samsung	Samsung SGH-E730
Samsung	Samsung SGH-E740
Samsung	Samsung SGH-E760
Samsung	Samsung SGH-E770
Samsung	Samsung SGH-E780
Samsung	Samsung SGH-E790
Samsung	Samsung SGH-E80
Samsung	Samsung SGH-E810

Samsung	Samsung SGH-E820
Samsung	Samsung SGH-E830
Samsung	Samsung SGH-E840
Samsung	Samsung SGH-E850
Samsung	Samsung SGH-E860V
Samsung	Samsung SGH-E900
Samsung	Samsung SGH-F300
Samsung	Samsung SGH-F330
Samsung	Samsung SGH-F700V
Samsung	Samsung SGH-i520
Samsung	Samsung SGH-i550
Samsung	Samsung SGH-i750
Samsung	Samsung SGH-J600
Samsung	Samsung SGH-J750
Samsung	Samsung SGH-L760
Samsung	Samsung SGH-L760V
Samsung	Samsung SGH-P300
Samsung	Samsung SGH-P308
Samsung	Samsung SGH-P310
Samsung	Samsung SGH-P400
Samsung	Samsung SGH-P410
Samsung	Samsung SGH-P900
Samsung	Samsung SGH-P910
Samsung	Samsung SGH-P920
Samsung	Samsung SGH-P930
Samsung	Samsung SGH-P940
Samsung	Samsung SGH-S300
Samsung	Samsung SGH-S300M
Samsung	Samsung SGH-S400i
Samsung	Samsung SGH-S401i
Samsung	Samsung SGH-S500
Samsung	Samsung SGH-S501i
Samsung	Samsung SGH-S720i
Samsung	Samsung SGH-S730i
Samsung	Samsung SGH-U600
Samsung	Samsung SGH-U700
Samsung	Samsung SGH-U700V
Samsung	Samsung SGH-V200
Samsung	Samsung SGH-X100
Samsung	Samsung SGH-X160
Samsung	Samsung SGH-X200
Samsung	Samsung SGH-X210
Samsung	Samsung SGH-X426
Samsung	Samsung SGH-X450
Samsung	Samsung SGH-X46
Samsung	Samsung SGH-X480
Samsung	Samsung SGH-X481
Samsung	Samsung SGH-X500
Samsung	Samsung SGH-X510
Samsung	Samsung SGH-X510V
Samsung	Samsung SGH-X600
Samsung	Samsung SGH-X610
Samsung	Samsung SGH-X640

Samsung	Samsung SGH-X65
Samsung	Samsung SGH-X660
Samsung	Samsung SGH-X660V
Samsung	Samsung SGH-X670
Samsung	Samsung SGH-X680V
Samsung	Samsung SGH-X700
Samsung	Samsung SGH-X800
Samsung	Samsung SGH-X820
Samsung	Samsung SGH-X830
Samsung	Samsung SGH-Z Series
Samsung	Samsung SGH-Z130
Samsung	Samsung SGH-Z150
Samsung	Samsung SGH-Z170
Samsung	Samsung SGH-Z220
Samsung	Samsung SGH-Z230
Samsung	Samsung SGH-Z240
Samsung	Samsung SGH-Z240E
Samsung	Samsung SGH-Z310
Samsung	Samsung SGH-Z320i
Samsung	Samsung SGH-Z370
Samsung	Samsung SGH-Z400V
Samsung	Samsung SGH-Z400V
Samsung	Samsung SGH-Z510
Samsung	Samsung SGH-Z540
Samsung	Samsung SGH-Z540V
Samsung	Samsung SGH-Z560
Samsung	Samsung SGH-Z560VH
Samsung	Samsung SGH-Z620
Samsung	Samsung SGH-Z630
Samsung	Samsung SGH-Z650i
Samsung	Samsung SGH-Z710
Samsung	Samsung SGH-Z720
Samsung	Samsung SGH-Z720M
Samsung	Samsung SGH-ZV10
Samsung	Samsung SGH-ZV30
Samsung	Samsung SGH-ZV40
Samsung	Samsung SGH-ZV50
Samsung	Samsung SGH-ZV60
Samsung	Samsung SPH-A620
Samsung	Samsung SPH-a660/VI660
Samsung	SGH-U800
Samsung	Samsung C3050
Samsung	Samsung E1310B
Samsung	Samsung E250i
Samsung	Samsung GT-C5130S
Samsung	Samsung GT-M5650
Samsung	Samsung GT-S3650
Samsung	Samsung GT-S5230
Samsung	Samsung GT-S7550
Samsung	Samsung S3030
Samsung	Samsung S3500
Samsung	Samsung SAMSUNG B2100
Samsung	Samsung SAMSUNG B5702

Samsung	Samsung SAMSUNG C5212
Samsung	Samsung SAMSUNG D900E
Samsung	Samsung SAMSUNG GT-B2700
Samsung	Samsung SAMSUNG GT-B3410
Samsung	Samsung SAMSUNG GT-B5722
Samsung	Samsung SAMSUNG GT-S3100
Samsung	Samsung SAMSUNG M3200
Samsung	Samsung SAMSUNG M3510
Samsung	Samsung SAMSUNG S3110
Samsung	Samsung SAMSUNG S3600
Samsung	Samsung SAMSUNG S5200
Samsung	Samsung SAMSUNG SGH-D608
Samsung	Samsung SAMSUNG SGH-D780
Samsung	Samsung SAMSUNG SGH-D880
Samsung	Samsung SAMSUNG SGH-D980
Samsung	Samsung SAMSUNG SGH-E251
Samsung	Samsung SAMSUNG SGH-E598
Samsung	Samsung SAMSUNG SGH-F250
Samsung	Samsung SAMSUNG SGH-F258
Samsung	Samsung SAMSUNG SGH-F278
Samsung	Samsung SAMSUNG SGH-G600
Samsung	Samsung SAMSUNG SGH-J150
Samsung	Samsung SAMSUNG SGH-J700
Samsung	Samsung SAMSUNG SGH-J700i
Samsung	Samsung SAMSUNG SGH-J700V
Samsung	Samsung SAMSUNG SGH-J770
Samsung	Samsung SAMSUNG SGH-L310
Samsung	Samsung SAMSUNG SGH-L600
Samsung	Samsung SAMSUNG SGH-L700
Samsung	Samsung SAMSUNG SGH-M200
Samsung	Gabri
Samsung	GT-I8510
Samsung	186
Samsung	GT-i8320
Samsung	GT-I8910
Samsung	GT-M8800
Samsung	GT-S5600
Samsung	GT-S5603
Samsung	GT-S7350i
Samsung	M7600
Samsung	S7220
Samsung	S7350
Samsung	S8000
Samsung	S8300
Samsung	S8300V
Samsung	S7330
Samsung	SGH-A412
Samsung	SGH-F480
Samsung	SGH-F480V
Samsung	SGH-F490
Samsung	SGH-F490V
Samsung	SGH-G400
Samsung	SGH-G800

Samsung	SGH-G810
Samsung	SGH-i450
Samsung	SGH-i560
Samsung	SGH-J630
Samsung	SGH-L770V
Samsung	SGH-U708
Samsung	SGH-U900
Samsung	SGH-U900V
Samsung	GT-S5600V
Samsung	I7110 soul
SHARP	Sharp 770SH
SHARP	Sharp 903
SHARP	Sharp GX Series
SHARP	Sharp TQ-GX Series
SHARP	Sharp V902
Siemens	BenQ-Siemens S68
Siemens	Siemens 3618
Siemens	Siemens 6618
Siemens	Siemens A60
Siemens	Siemens A62
Siemens	Siemens A65
Siemens	Siemens A75
Siemens	Siemens AX72
Siemens	Siemens C110
Siemens	Siemens C25
Siemens	Siemens C35i
Siemens	Siemens C55
Siemens	Siemens C60
Siemens	Siemens C65
Siemens	Siemens C65
Siemens	Siemens C72
Siemens	Siemens C75
Siemens	Siemens CF62
Siemens	Siemens CF75
Siemens	Siemens CFX65
Siemens	Siemens CL75
Siemens	Siemens CX65
Siemens	Siemens CX6V
Siemens	Siemens CX70
Siemens	Siemens CX75
Siemens	Siemens EF81
Siemens	Siemens EL71
Siemens	Siemens M35i
Siemens	Siemens M50
Siemens	Siemens M55
Siemens	Siemens M65
Siemens	Siemens M6V
Siemens	Siemens M75
Siemens	Siemens M81
Siemens	Siemens MC35i
Siemens	Siemens MC45
Siemens	Siemens MC60
Siemens	Siemens MC75

Siemens	Siemens ME45
Siemens	Siemens ME75
Siemens	Siemens S25
Siemens	Siemens S35i
Siemens	Siemens S40
Siemens	Siemens S40/S42
Siemens	Siemens S45
Siemens	Siemens S45i
Siemens	Siemens S46
Siemens	Siemens S55
Siemens	Siemens S56
Siemens	Siemens S65
Siemens	Siemens S6V
Siemens	Siemens S75
Siemens	Siemens SK65
Siemens	Siemens SK6R
Siemens	Siemens SL42
Siemens	Siemens SL45
Siemens	Siemens SL55
Siemens	Siemens SL65
Siemens	Siemens SL75
Siemens	Siemens SP65
Siemens	Siemens ST60
Siemens	Siemens SX1
Siemens	Siemens SX45
Siemens	Siemens SXG75
Sony Ericsson	Sony Ericsson G502
Sony Ericsson	Sony Ericsson G502c
Sony Ericsson	Sony Ericsson K530c
Sony Ericsson	Sony Ericsson K530i
Sony Ericsson	Sony Ericsson K550i/K550c
Sony Ericsson	Sony Ericsson k790a
Sony Ericsson	Sony Ericsson k790i
Sony Ericsson	Sony Ericsson K818c
Sony Ericsson	Sony Ericsson T658c
Sony Ericsson	Sony Ericsson TM506
Sony Ericsson	Sony Ericsson w380a
Sony Ericsson	Sony Ericsson w380i
Sony Ericsson	Sony Ericsson W518a
Sony Ericsson	Sony Ericsson W610i/W610c
Sony Ericsson	Sony Ericsson W660i and W610c
Sony Ericsson	Sony Ericsson W830i/W830c
Sony Ericsson	Sony Ericsson W902
Sony Ericsson	Sony Ericsson W980
Sony Ericsson	Sony Ericsson Z750a
Sony Ericsson	Sony Ericsson Z750i
Sony Ericsson	Sony Ericsson Z780
Sony Ericsson	Sony Ericsson W888c
Sony Ericsson	Sony Ericsson 530i
Sony Ericsson	Sony Ericsson C510 MB
Sony Ericsson	Sony Ericsson C901
Sony Ericsson	Sony Ericsson C901a
Sony Ericsson	Sony Ericsson C902

Sony Ericsson	Sony Ericsson C903
Sony Ericsson	Sony Ericsson C903a
Sony Ericsson	Sony Ericsson C905
Sony Ericsson	Sony Ericsson C905a
Sony Ericsson	Sony Ericsson C905c
Sony Ericsson	Sony Ericsson D750i/K758c
Sony Ericsson	Sony Ericsson F500 Series
Sony Ericsson	Sony Ericsson G705u
Sony Ericsson	Sony Ericsson J300 series
Sony Ericsson	Sony Ericsson K300 series
Sony Ericsson	Sony Ericsson K310i
Sony Ericsson	Sony Ericsson K320i
Sony Ericsson	Sony Ericsson K500 Series
Sony Ericsson	Sony Ericsson K508 Series
Sony Ericsson	Sony Ericsson K510i
Sony Ericsson	Sony Ericsson K550i
Sony Ericsson	Sony Ericsson K550im
Sony Ericsson	Sony Ericsson K600i
Sony Ericsson	Sony Ericsson K608i
Sony Ericsson	Sony Ericsson K610i
Sony Ericsson	Sony Ericsson K610im
Sony Ericsson	Sony Ericsson K630i
Sony Ericsson	Sony Ericsson k660i
Sony Ericsson	Sony Ericsson K700
Sony Ericsson	Sony Ericsson K700i
Sony Ericsson	Sony Ericsson K750i
Sony Ericsson	Sony Ericsson K770i
Sony Ericsson	Sony Ericsson K800
Sony Ericsson	Sony Ericsson K800i
Sony Ericsson	Sony Ericsson K810i
Sony Ericsson	Sony Ericsson K850i
Sony Ericsson	Sony Ericsson M600i
Sony Ericsson	Sony Ericsson P1i
Sony Ericsson	Sony Ericsson P800
Sony Ericsson	Sony Ericsson P900
Sony Ericsson	Sony Ericsson P910a
Sony Ericsson	Sony Ericsson P910i
Sony Ericsson	Sony Ericsson P990i
Sony Ericsson	Sony Ericsson S500i/S500c
Sony Ericsson	Sony Ericsson S700 series
Sony Ericsson	Sony Ericsson S710 series
Sony Ericsson	Sony Ericsson T300
Sony Ericsson	Sony Ericsson T300
Sony Ericsson	Sony Ericsson T312
Sony Ericsson	Sony Ericsson T316
Sony Ericsson	Sony Ericsson T610
Sony Ericsson	Sony Ericsson T610 Series
Sony Ericsson	Sony Ericsson T618
Sony Ericsson	Sony Ericsson T62u
Sony Ericsson	Sony Ericsson T630
Sony Ericsson	Sony Ericsson T630-T628
Sony Ericsson	Sony ericsson T630/T628
Sony Ericsson	Sony Ericsson T650i

Sony Ericsson	Sony Ericsson T700
Sony Ericsson	Sony Ericsson T707
Sony Ericsson	Sony Ericsson T707
Sony Ericsson	Sony Ericsson T707a
Sony Ericsson	Sony Ericsson V600i
Sony Ericsson	Sony Ericsson V630i
Sony Ericsson	Sony Ericsson V630i/K618i
Sony Ericsson	Sony Ericsson V800
Sony Ericsson	Sony Ericsson W200
Sony Ericsson	Sony Ericsson w300i
Sony Ericsson	Sony Ericsson W350a
Sony Ericsson	Sony Ericsson W350i/c
Sony Ericsson	Sony Ericsson W508
Sony Ericsson	Sony Ericsson W508a
Sony Ericsson	Sony Ericsson W550i
Sony Ericsson	Sony Ericsson w580
Sony Ericsson	Sony Ericsson W580i/W580c
Sony Ericsson	Sony Ericsson W595
Sony Ericsson	Sony Ericsson W600Series
Sony Ericsson	Sony Ericsson W660i
Sony Ericsson	Sony Ericsson W700i
Sony Ericsson	Sony Ericsson W705
Sony Ericsson	Sony Ericsson W705u
Sony Ericsson	Sony Ericsson w710
Sony Ericsson	Sony Ericsson W760
Sony Ericsson	Sony Ericsson W800
Sony Ericsson	Sony Ericsson W810i
Sony Ericsson	Sony Ericsson W850
Sony Ericsson	Sony Ericsson W850i
Sony Ericsson	Sony Ericsson W880i
Sony Ericsson	Sony Ericsson W890i
Sony Ericsson	Sony Ericsson W900
Sony Ericsson	Sony Ericsson W910i
Sony Ericsson	Sony Ericsson W950i
Sony Ericsson	Sony Ericsson Z1010
Sony Ericsson	Sony Ericsson Z1010 Series
Sony Ericsson	Sony Ericsson Z310i
Sony Ericsson	Sony Ericsson Z500
Sony Ericsson	Sony Ericsson Z520a
Sony Ericsson	Sony Ericsson Z520i
Sony Ericsson	Sony Ericsson Z530i/Z530c
Sony Ericsson	Sony Ericsson Z550i/Z550c
Sony Ericsson	Sony Ericsson Z555a
Sony Ericsson	Sony Ericsson Z555i
Sony Ericsson	Sony Ericsson Z600
Sony Ericsson	Sony Ericsson Z610i
Sony Ericsson	Sony Ericsson Z710i/Z710c
Sony Ericsson	Sony Ericsson Z800i
Sony Ericsson	1021012-BVP910i
Sony Ericsson	1130102-BVT39m
Sony Ericsson	1130201-BVT68
Sony Ericsson	1130202-BVT68
Sony Ericsson	7130501-BVP800

Sony Ericsson	AAB-1021031-BV
Sony Ericsson	AAB-1021051-BV
Sony Ericsson	AAD-3252022-BV
Sony Ericsson	FAD-3022011-BV
Sony Ericsson	FAD-3022013-BV
Sony Ericsson	Sony Ericsson AAB-1022111-BV
Sony Ericsson	Sony Ericsson AAC-1052022-BV
Sony Ericsson	Sony Ericsson AAC-1052051-BV
Sony Ericsson	Sony Ericsson AAC-1052141-BV
Sony Ericsson	Sony Ericsson AAD-3022121-BV
Sony Ericsson	Sony Ericsson AAD-3052042-BV
Sony Ericsson	Sony Ericsson AAD-3052071-BV
Sony Ericsson	Sony Ericsson AAD-3052091-BV
Sony Ericsson	Sony Ericsson AAD-3052111-BV
Sony Ericsson	Sony Ericsson AAD-3052121-BV
Sony Ericsson	Sony Ericsson AAD-3880020-BV
Sony Ericsson	Sony Ericsson AAD-3880032-BV
Sony Ericsson	Sony Ericsson AAD-3880039-BV
Sony Ericsson	Sony Ericsson AAD-3880046-BV
Sony Ericsson	Sony Ericsson C702
Sony Ericsson	Sony Ericsson F305
Sony Ericsson	Sony Ericsson FAB-1022012-BV
Sony Ericsson	Sony Ericsson FAD-3022018-BV
Sony Ericsson	Sony Ericsson G705
Sony Ericsson	Sony Ericsson G900
Sony Ericsson	Sony Ericsson MD400
Sony Ericsson	Sony Ericsson Sony Ericsson K850
Sony Ericsson	Sony Ericsson Sony Ericsson V640
Sony Ericsson	Sony Ericsson W 960i
Sony Ericsson	Sony Ericsson W302
Sony Ericsson	Sony Ericsson w580i
Sony Ericsson	Sony Ericsson W595s
Sony Ericsson	Sony Ericsson W715 Besser
Sony Ericsson	Sony Ericsson W995
Sony Ericsson	Sony Ericsson Z770i
Sony Ericsson	Sony Ericsson Z800i
SonyEricsson	SonyEricsson GC86
Toshiba	Toshiba 803
Toshiba	Toshiba TS 921
Toshiba	Toshiba-Vodafone 803T
Vodafone	Vodafone V720
Vodafone	Vodafone V715
Vodafone	Vodafone V810
Vodafone	Vodafone VF710
Vodafone	Vodafone Group V725
Vodafone	Vodafone Group V736
Vodafone	Vodafone K4505